



Impedance of RF trace should be controlled by 50 ohm and the length should be kept as short as possible.

VIN: 3.3V ~ 4.2V
 INT1: Main Board <-- Slave
 INT2: Main Board --> Slave

P1P2P3P4
 P8P7P6P5

Seeed Studio

TITLE: Xadow GPS v2

CC-BY-SA	Design: Zelin Cai	Check:
	Date: 2015/9/14 14:49:19	Vision: